

BP42 Installation Instructions



Push the front loop over the front sight as illustrated.



Push the metal buckle through the front swivel as shown.



It looks like this when done. It is now silent and secure, and the wire inside the loop prevents melt through.



Place the large loop over the buttstock and push the loop lock through the swivel exactly as shown.



Continue until it looks like this.



This is how it will look when done. The large loop will now pass over the butt of the rifle as it is raised to aim, and will go back on when the weapon is lowered, keeping the rifle upright.